

Blend Cycle Library


The Stealth's preprogrammed blend cycles will handle nearly every blending need—from milkshakes to margaritas to the smoothest of smoothies.

1	Salsa	7 seconds	15	Large Milkshake 3	35 seconds
2	Batter	23 seconds	16	Small Smoothie with Fresh Fruit	20 seconds
3	Whole Juice	50 seconds	17	Medium Smoothie 1	19 seconds
4	Soup	90 seconds	18	Medium Smoothie 2	23 seconds
5	Ice Cream	45 seconds	19	Medium Smoothie 3	23 seconds
6	Small Margarita / Ice Cappuccino	14 seconds	20	Medium Smoothie 4	25 seconds
7	Large Ice Cappuccino	20 seconds	21	Large Smoothie 1	28 seconds
8	Ice Crush / Milkshake	35 seconds	22	Large Smoothie 2	32 seconds
9	Small Slushy / Milkshake	12 seconds	23	Large Smoothie 3	36 seconds
10	Small Milkshake	18 seconds	24	Large Smoothie 4	40 seconds
11	Granita / Medium Milkshake	14 seconds	25	Large Smoothie 5	50 seconds
12	Milkshake with Frozen Fruit	18 seconds	26	Large Smoothie 6	40 seconds
13	Small Milkshake	14 seconds	27	Large Smoothie 4	38 seconds
11	Granita / Medium Milkshake	14 seconds	25	Large Smoothie 5	50 seconds
12		18 seconds	26		40 seconds

29	Ultrathick Smoothie 3	67 seconds	37	Pulse at Speed 1	Pulse
30	Ultrathick Smoothie 4	23 seconds	38	Pulse at Speed 2	Pulse
31	50 Seconds at Speed 1	50 seconds	39	Pulse at Speed 3	Pulse
32	50 Seconds at Speed 2	50 seconds	40	Pulse at Speed 5	Pulse
33	50 Seconds at Speed 3	50 seconds	41	Pulse at Speed 7	Pulse
34	50 Seconds at Speed 5	50 seconds	42	Pulse at Speed 9	Pulse
35	50 Seconds at Speed 7	50 seconds	43	Disable Button	Disabled
36	50 Seconds at Speed 9	50 seconds			

Blend Wizard™ Web App

Log in to blendtec.com/commercial/program to download even more from our vast library of blend cycles, alter cycles to meet your specific needs, or even create your own cycles from scratch!




OWN CYCLES FROM SCRATCH:



Blendtec
COMMERCIAL



Stealth Button Guide (in programming mode)



The Blendtec Stealth incorporates the latest technology available in today's commercial blenders—not the least of which is the state-of-the-art control surface that allows you to manage and fine-tune your blender's programming.

Selecting a Profile

To select a profile, follow the steps below:

- Enter programming mode by touching and holding  for 3 seconds.
- Touch  to select Profiles.
 - To choose 1 of the standard profiles preprogrammed on the machine, select Standard Profiles by touching .
 - To choose a custom profile designed via the Blend Wizard, touch  to scroll to Custom Profiles and then touch .
- After selecting the standard or custom profile category, touch  to scroll through the profiles in the category, and touch  to select the desired profile.
- The LED screen will list the selected profile and the question "Make this the active profile?" Touch  to load the blender with the profile, or touch  to cancel and return to the previous menu.

Changing the Programmed Cycle Buttons

After loading the desired profile, complete the following steps to change 1 of the blend cycles in the profile:

- Enter programming mode by touching and holding  for 3 seconds.
- Touch  to scroll to the second menu item (Blend Cycles), and then touch .
- profile, or touch  to cancel and return to the previous menu.

Changing the Programmed Cycle Buttons

After loading the desired profile, complete the following steps to change 1 of the blend cycles in the profile:

- Enter programming mode by touching and holding  for 3 seconds.

- Touch  to scroll to the desired cycle, and then touch .
- The LED screen will then prompt you to choose which number on the control surface you want to assign the cycle to. Touch the number, and then touch  to program the button with the selected cycle.

Creating Profiles and Cycles via the Blend Wizard™

In addition to using the profiles and cycles preprogrammed on your blender, you can use the Blend Wizard to create custom profiles that include current Blendtec cycles and/or custom cycles. For instructions on using the Blend Wizard to easily develop custom profiles and cycles, visit blendtec.com/commercial/program.

Importing Custom Profiles and Cycles to the Blender

Once you have completed the Blend Wizard instructions and transferred a custom profile file to a USB flash drive, follow the steps below to import the file to the blender.

- Use a Phillips screwdriver to remove the USB cover at the top of the right side of the blender.
- Insert the USB flash drive into the blender's USB port.
- If the blender is in manual or automatic operation mode, the USB drive menu will automatically load on the LED screen. If the LED screen is already in programming mode, go to the main menu, touch  to scroll to menu item 5 (USB Flash Drive), and then touch .
- From the USB flash drive menu, touch  to select option 1 (Import Profile).
- Touch  to scroll through the items on the flash drive and locate the desired custom profile file (by default named stealth.bpf). (Note: Items with a + sign next to them are folders; if the custom profile file is in a folder, touch  to open the folder and see the files in the folder.) Select the desired file by touching .
- Touch  to start the import process. After the file has been imported, the custom profile will be automatically loaded as the active profile on the blender.
- Remove the USB drive from the blender, and secure the USB cover on the right side of the blender.
- Touch  to start the import process. After the file has been imported, the custom profile will be automatically loaded as the active profile on the blender.

Smoothie Profile			Multipurpose Profile		
1		20 seconds	1		18 seconds
2		25 seconds	2		14 seconds
3		14 seconds	3		14 seconds
4		23 seconds	4		25 seconds
5		40 seconds	5		40 seconds
6		50 seconds	6		50 seconds
	Pulse at Speed 7	Pulse		Pulse at Speed 7	Pulse
Coffee Profile			Milkshake Profile		
1		14 seconds	1		18 seconds
2		20 seconds	2		14 seconds
3		12 seconds	3		18 seconds
4		14 seconds	4		24 seconds
5		32 seconds	5		27 seconds
	Small Slushy / Milkshake	50 seconds		Milkshake with Frozen Fruit	25 seconds
4		14 seconds	4		24 seconds
5		32 seconds	5		27 seconds